

Never reverse the polarity of the 12V input. Also, observe your battery pack polarity. Reverse polarity cause permanent damage.



Unpack the unit from the box.



Attach the agitator clips to a 12V power supply



Observe battery polarity & terminal location



Install battery pack as shown



Secure all thumb screws



Select Ni-Cd & Ni-MH mode



Then select equalizing or conditioning mode



Press start button to start discharging

Voltage cutoff: Ni-MH Equalizing: 0.9V/cell, Ni-MH Conditioning: 0.6V/cell  
Voltage cutoff: Ni-Cd Equalizing: 0.9V/cell, Ni-Cd Conditioning: 0.1V/cell